www.buyersproducts.com
Phone (440) 974-8888
Fax 800-841-8003

Installation Instructions

8891031 **Wireless Mini Light Bar with Remote**

Power on the wireless mini light bar by pressing the power button on top of the unit. Pressing the top button again will select the next flash pattern.

Power off the wireless mini light bar by pressing and holding the power button for three (3) seconds. When the unit is again powered on, it will resume the flash pattern that was selected when it was powered off.

When the light bar is powered on, the light near the power button indicates the battery level according to chart 1.
IMPORTANT! Always make sure that the charging port plug is fully inserted during operation to prevent damage from dirt or moisture.

Charging the Wireless Light Bar

Before using the wireless light bar, it must be charged. To charge the unit, remove the plug from the connector on the bottom of the light bar and insert the power cord into the connector. Plug the power cord into an appropriate auxiliary power connection in your vehicle.
The unit will reach full charge in 4.5 hours. Charging status is indicated by the light near the power button according to the chart 1. The light will turn green when charging is complete.
When charging is complete, remove the power cord and ensure that the sealing plug is fully inserted into the charging connector. This will ensure that the light bar is protected from dirt and moisture.

Using the Wireless Remote

The remote may be used to switch the power off or back on again. To select the flash pattern using the wireless remote, press the mode button. Pressing the mode button will select the next flash pattern according to Chart 2.

Pairing the Remote with the Wireless Mini Light Bar

1. With the light bar powered off, press and release the power button, and then quickly press and hold the power button until the green light near the power button begins flashing.
2. Then press the power button on the remote. The green light will become red and continue flashing.
3. Then press the mode button on the remote. The flashing red light will switch to a steady green light and the next flash pattern will be selected.
4. Begin using the remote as normal. Use the power button to switch the unit on and off. Use the mode button to select the flash pattern.

You can pair two light bars with a single remote by repeating the above process with a second light bar.



⚠ WARNING

Do not look directly into LED's while in operation; may cause momentary blindness and/or eye damage.

⚠ WARNING

It is not recommended to use magnetically mounted warning devices on vehicles in motion. Usage is at the sole risk and responsibility of the user.

Chart 1

STATUS	LEVEL	LIGHT INDICATION
In Use	0-9%	Flashing Red
	10-29%	Red
	30%-69%	Yellow
	70%-100%	Green
Charging	0-29%	Flashing Red
	30%-69%	Flashing Yellow
	70%-99%	Flashing Green
	100%	Green

Chart 2 - Flash Patterns

NUMBER	PATTERN
1	single flash
2	double flash
3	triple flash
4	quad flash
5	Quint flash
6	clockwise chase
7	counterclockwise chase

WARRANTY

Buyers Products Co. warrants all truck/trailer hardware manufactured or distributed by it, to be free from defects in material and workmanship for a period of one year from date of shipment. Parts must be properly installed and used under normal conditions. Any product which has been altered, including modification, misuse, accident or lack of maintenance will not be considered under warranty. Normal wear is excluded. The sole responsibility of Buyers Products Co. under this warranty is limited to repairing or replacing any part or parts which are returned, prepaid, and are found to be defective by Buyers Products Co. Authorization from Buyers Products Co. must be obtained before returning any part. No charges for transportation or labor performed on Buyers' products will be allowed under this warranty.