

SnowDogg® Snowplow Headlight Adapter

INSTALLATION INSTRUCTIONS

16071090

GM 8-PIN 1500 2016+

INSTRUCTIONS

- 1.** Disconnect both PS and DS side truck headlights from the truck harness.
- 2.** Connect the 16071090 adapters to the OEM headlight connectors and truck harness connectors.
- 3.** Connect the 16071090 adapters to the universal light harness connectors included with the snowplow. This is part of the harness with the relay module.
- 4.** Check all light functionality before operating the plow.