

SnowDogg® Snowplow Headlight Adapter

INSTALLATION INSTRUCTIONS

16071190

FORD 4-PIN HEADLIGHT CONNECTOR, 2015+

INSTRUCTIONS

- 1.** Disconnect both PS and DS side truck headlights from the truck harness.
- 2.** Connect the 16071190 adapters to the OEM headlight connectors and truck harness connectors.
- 3.** Connect the 16071190 adapters to the universal light harness connectors included with the snowplow. This is part of the harness with the relay module.
- 4.** Use an included Tap connector to tap the BROWN wire into your PARK light circuit on both the PS and DS circuits.
- 5.** Use an included Tap connector to tap the PURPLE wire into the TURN light circuit on both the PS and DS circuits.
- 6.** Check all light functionality before operating the plow.