

SnowDogg® Snowplow Headlight Adapter

INSTALLATION INSTRUCTIONS

16071210

THIS IS ONLY INTENDED FOR USE WITH THE FOLLOWING APPLICATIONS:

'99-'01 DODGE 1500 AND '99-'02 DODGE 2500/3500

1. Install RELAY AND CONTROL harnesses per 16071120 or 16071130 instructions (following switched ground instructions)
2. Disconnect ORANGE and BLACK/WHITE wires from the RELAY HARNESS from the BLACK wire (from the CONTROL HARNESS previously connected during 16071120/16071120 installation) and attach to PIN 87 of the relay per figure 1. The BLACK wire from the CONTROL HARNESS is not used and can be taped off.
3. Connect a minimum 2A switched ignition source to pin 85. DO NOT USE THE RED/WHITE wire from the CONTROL HARNESS.
4. Connect the black ground harness on the relay to a good ground (chassis or battery)
5. Pin 87A (if present) on the relay is NOT USED.
6. Verify function of headlights, parking lights, and turn signals on the plow and truck.

