

# **SnowDogg® Snowplow Headlight Adapter**

## **INSTALLATION INSTRUCTIONS**

### **16071270**

#### **RAM 12-PIN 1500 2019+ HALOGEN**

#### **INSTRUCTIONS**

1. Disconnect both PS and DS side truck headlights from the truck harness.
2. Connect the 16071270 adapters to the OEM headlight connectors and truck harness connectors.
3. Connect the 16071270 adapters to the universal light harness connectors included with the snowplow. This is part of the harness with the relay module.
4. Check all light functionality before operating the plow.