
www.buyersproducts.com
Phone (440) 974-8888
Fax 800-841-8003

Installation Instructions


BPUGDM **Connection Kit**

1. Connect linkage arm to pump spool.
2. Connect pivot arms to pump and linkage arm.
3. Connect bracket to pump using existing bolts and washers. Be sure to re-torque bolts on pump to 200 ft./lbs. (do not estimate a torque wrench must be used).
4. Connect cable using clamp to bracket as shown.
5. Connect jam nut and pivot to cable rob end. Then connect assemble to linkage arm. Adjust pivot for proper operation and secure jam nut.


BPUGDMCCW



View of Bracket Mounting Holes



BPUGDMCW



View of Bracket Mounting Holes

